



Electra Steam, Inc.


4407 Martinsburg Pike
Clear Brook, VA
22624
USA

Phone: 540-662-3811
Fax: 540-665-8101
email: Sales@reimersinc.com
web: www.reimersinc.com

MODEL:

SERIAL #:

RX36 - 120 Series Steam Boiler Instructions Manual



LIMITED WARRANTY - STEAM BOILERS

Reimers Electra Steam, Inc. warrants the following products of its own manufacture against defects in materials and workmanship under normal use and service. This warranty is in lieu and excludes all other expressed or implied warranties or merchantability of fitness for any particular use. No person is authorized to extend the terms of this warranty or assume any other liability except by written statement signed by an officer of Reimers Electra Steam, Inc. Clear Brook, Virginia 22624.

WARRANTY PERIOD

The pressure vessel, electrical and mechanical components are warranted for one year from date of shipment from Reimers Electra Steam, Inc. in Clear Brook, VA 22624.

LIMITATIONS

Products must be installed, used and maintained in accordance with our instructions, including reasonable and necessary maintenance by the user. Users are responsible for the suitability of the products to their application. There is no warranty for damage resulting from improper installation, abuse, power failure, fire, flood, lightening, improper water, misuse, improper specification, misapplication or other operating conditions beyond our control or parts that are normally expendable in usual course of operation.

Claims against carriers for damage in transit must be filed by the buyer. Reimers liability, if any, will not exceed the price of Reimers products claimed to be defective.

Components manufactured by any supplier other than Reimers shall bear only that warranty made by the manufacturer of that product and service for that warranty shall be the responsibility of that manufacturer and not Reimers.

REMEDY

Claims under this Limited Warranty must be made by obtaining a Return Authorization Number from our office (PHONE: 540-662-3811, FAX: 540-665-8101) and returning defective part, freight prepaid to: Reimers Electra Steam, Inc., 4407 Martinsburg Pike, Clear Brook, Virginia 22624.

Defective items will be repaired or replaced as necessary within a reasonable time without charge, other than incidental charges such as freight prepayment. Such repair or replacement within a reasonable time is the exclusive remedy available from Reimers Electra Steam, Inc., under this Limited Warranty.

CONSEQUENTIAL DAMAGES

Reimers Electra Steam, Inc., is not liable for labor costs incurred in the removal, reinstallation, or unauthorized repair of product, or for damages of any type whatsoever, including incidental and/or consequential damages.

THIS WARRANTY SUPERSEDES ALL PREVIOUS WARRANTIES.

Important Safety Information

You have just purchased a quality steam boiler designed to the ASME Boiler Code and registered with the National Board of Boiler Inspectors. Treat this industrial equipment with care and respect. It is safe when installed, maintained, and used properly. Read the instruction carefully and contact the factory if you have any questions.

WARNING

Read this manual before installing and using this product.

Failure to do so can result in serious injury or death.

Your boiler should be marked with a complete set of WARNING/CAUTION labels shown below. If one of these labels is missing, please contact our factory immediately.

US and All Other Non-Francophone Countries **Canada and All Other Francophone Countries**

Located on electrical enclosure door

 WARNING	 ADVERTENCIA	 WARNING	 AVERTISSEMENT
 Risk of electric shock. This boiler is connected to more than one branch circuits. Disconnect all power and control circuits before servicing.	 Riesgo the electrochoque. Esta caldera está conectado a mas de un circuito de alimentación. Desconecte los todos circuitos antes de realizar el mantenimiento.	 Risk of electric shock. This boiler is connected to more than one branch circuits. Disconnect all power and control circuits before servicing.	 Risque de choc électrique. Cette chaudière est reliée à plusieurs circuits d'alimentation. Débrancher tous les circuits d'alimentation avant l'entretien.
 Read and understand the operator's manual before using this boiler.	 Lea y comprenda el manual de instrucciones antes de utilizar esta	 Read and understand the operator's manual before using this boiler.	 Lire et comprendre les instructions avant d'utiliser cette chaudière.

Located on end caps of cylindrical boiler pressure vessel jacket

 WARNING	 ADVERTENCIA	 WARNING	 AVERTISSEMENT
 Risk of electric shock. Disconnect all branch circuits before removing this cover.	 Riesgo de electrochoque. Desconecte los todos circuitos antes de remover esta cubierta.	 Risk of electric shock. Disconnect all branch circuits before removing this cover.	 Risque de choc électrique. Débrancher tous les circuits avant de retirer le couvert.

Located on end caps of cylindrical boiler pressure vessel jacket

 CAUTION	 ATENCIÓN	 CAUTION	 PRUDENCE
 All exposed pipes and valves may be hot. Do not touch.	 Las tuberías y valvulas expuestas pueden estar calientes. No toque.	 All exposed pipes and valves may be hot. Do not touch.	 Tous les tuyaux et valves exposées peuvent être chauds Ne pas toucher

This manual contains safety messages. Each of the safety messages are preceded by one of the following signal word panels:

DANGER

Safety messages preceded by this label contain information, that if not followed will result in death or serious injury.

WARNING

Safety messages preceded by this label contain information, that if not followed could result in death or serious injury.

CAUTION

Safety messages preceded by this label contain information, that if not followed could result in minor or moderate injury.

NOTICE

Messages preceded by this label contain important information, but are not hazard-related.

Ensure that this manual is available to the boiler operator at any time.

Read carefully all safety labels attached to the boiler. If any safety label was damaged during shipment, contact the factory immediately:
Ph. 540-662-3811; e-mail: sales@reimersinc.com

1. BLOWDOWN VALVE: This valve is utilized to blow impurities from the boiler chamber. When opened, a large volume of hot water and steam is discharged. Ensure that this valve is properly piped for such discharge. State and local codes must be met as applicable.

2. ELECTRICAL: All field wiring to the boiler must be in accordance with the National Electric Code and any local codes that may apply. Wiring must be made by a competent certified electrician. Use copper wire only.

3. GAUGE GLASS: The gauge glass protector guards must be on at all times. When replacing the glass, be sure that the unit is not under pressure and is cool to touch. The gauge glass should be replaced once per year. If cracks or wear is evident, replace the gauge glass immediately.

4. MODIFICATION/MISUSE: This boiler has been designed and constructed in accordance with the ASME Boiler Code. Any modification or misuse can result in a dangerous situation. Reimers Electra Steam, Inc. is not liable for any product that has been modified or improperly used.

5. PRESSURE GAUGE: The pressure gauge indicates the internal pressure of the boiler. It can fail. Periodically have your boiler inspector compare the gauge with a known gauge utilizing the test valve

arrangement provided. Ensure that the boiler is cold, not pressurized and electrically disconnected.

6. REGISTRATION: Most states and cities require boiler registration and inspection. Check with your government authorities.

7. INSTALLATION AND REPAIR:

Installation and repair work of this unit must be performed only by experienced personnel. Before commencing a repair, ensure that the boiler is cold, not pressurized and electrically disconnected. All standard electrical and steam safety precautions must be taken during testing.

8. SAFETY VALVE: The safety valve is designed to discharge hot steam when the set pressure is exceeded. Ensure that the discharge port is pointing toward the back of the unit away from the operator or any aisles. Test the safety valve periodically to ensure that it is operating properly. Test carefully at full pressure by lifting lever using pliers and "slapping" shut. Steam discharge can scald. Ensure no one is exposed.

9. STEAM INSTALLATION:

Steam piping must be of black pipe, not galvanized. Work must be done by an experienced steam fitter. All state and local codes must be met as applicable.

12. WATER:

Ensure that all electrical components are in a dry location, free from any possibility of water soaking. Electric foot switches must not be placed on a wet floor. They must be placed on dry surface not subject to steam or water.

1. Installation

REIMERS ELECTRA STEAM, INC. boilers are heated by one or more immersion type heating elements. Automatic controls are provided to maintain pre-set operating pressure and proper water supply. Safety features include automatic low water cutoff, automatic pressure control, safety valve and visible water level gauge. Each boiler is manufactured in accordance with ASME I Power Boiler Code Standards and is individually inspected and stamped by an authorized National Board Insurance Inspector. All boilers are registered with the National Board of Boiler and Pressure Vessel Inspectors.

NOTICE

The ASME data plate is located on the end of the pressure vessel, behind the label stamped with the NATIONAL BOARD NUMBER of the unit.

When boiler is received, make sure it has not been damaged in shipment.

1.1 Location

Place the boiler in a level position, close to the equipment which it is to supply. This will insure minimum heat losses and allow more economical piping arrangements. All steam lines should be insulated. Review the overall dimensions of your boiler model on page 7 and 8 and the NFPA-70 requirements below to select proper boiler location.

a.) Working space:

Required working space for electric boilers is dictated by NFPA-70, Table 110.26 as follows:

Nominal Voltage To Ground (Volts)	Minimum Clear Distance		
	Condition 1	Condition 2	Condition 3
0 – 150	3ft (914mm)	3ft (914mm)	3ft (914mm)
151 – 600	3ft (914mm)	3.5ft (1.07m)	4ft (1.22m)

Note: Where the conditions are as follows:

Condition 1 — Exposed live parts on one side of the working space and no live or grounded parts on the other side of the working space, or exposed live parts on both sides of the working space that are effectively guarded by insulating materials.

Condition 2 — Exposed live parts on one side of the working space and grounded parts on the other side of the working space. Concrete, brick, or tile walls shall be considered as grounded.

Condition 3 — Exposed live parts on both sides of the working space.

(a) **Dead-Front Assemblies.** Working space shall not be required in the back or sides of assemblies, such as dead-front switchboards or motor control centers, where all connections and all renewable or adjustable parts, such as fuses or switches, are accessible from locations other than the back or sides. Where rear access is required to work on non-electrical parts on the back of enclosed equipment, a minimum horizontal working space of 762 mm (30 in.) shall be provided.

b.) **Alcove or closet installation per UL834:** Proper location of this boiler model with regard to combustible and noncombustible surfaces and materials is coded on the boiler name plate. The

following decoding sketch and description is provided for the user information:

R-, RH- and RHC- Models	Dimension In.						
	A	B	D	E _L	E _R	F	G
	18	A24	18	18	18	C	-

Description of dimensions and symbols

A – Clearance above top of boiler

B – Clearance from front of boiler

Prefix C to numeral indicates suitability for closet or alcove installation


Prefix A indicates suitability for alcove but not for closet installation

D – Clearance from back of boiler

E_L – Clearance from left side of boiler

E_R – Clearance from right side of boiler

F – Indicates type of flooring: "NC" for noncombustible floor / "C" for combustible floor. Numeral indicates minimum clearance below suspended units to combustible floor



1.2 Water Supply

On models with solenoid valve, connect incoming water supply to strainer on intake side of solenoid valve. On models with high pressure feed pump, connect incoming water supply to the inlet side of the pump. On models furnished with condensate return tank, connect water line to makeup valve located at tank end (See Instruction Supplement 1 in this manual). R, RH and RHC steam boiler models require four (4) gallons of feed water per hour for each 10 kW of electric heating capacity of the boiler. Lines should be of adequate size and meet local plumbing codes.

In order to ensure long term trouble-free boiler operation, we recommend that the water used as boiler feed water to be tested for hardness. If the water in your area is harder than 1grain (17mg/L), use a water softener. The main cause for premature heating element failure in electric steam boilers is water hardness.

If severe corrosion during inspection of the pressure vessel as indicated in chapter 3.4 of this manual becomes evident, additional tests of your boiler feed water must be performed. A water analysis should be performed by a qualified and recognized water treatment company located in your area.

Recommended levels for boiler feed water:

WATER PROPERTY	MAX. LIMIT
Total hardness	17 mg/L
Dissolved Oxygen	0.04 mg/L
Total Iron	0.1 mg/L
Total Copper	0.05 mg/L
pH	> 8.5
Specific Resistivity	25kΩ * cm

Recommended levels for boiler water (water inside pressure vessel when boiler operating):

PROPERTIES	MAX. LIMIT
Total Alkalinity	350 mg/L
Total Dissolved Solids	3500 mg/L
Total Suspended Solids	300 mg/L
pH	10.5 - 12

NOTICE

Do not add any chemicals to the boiler feed water unless specifically recommended by a qualified and recognized water treatment company.

1.3 Steam Outlet

CAUTION

All piping from and to the boiler must comply with the A.S.M.E. B31.1 Power Piping Code. All State and local codes must be met. All piping must be done by a qualified steam fitter.

Connect steam line of sufficient size from steam line valve to the equipment. Steam piping must be black steel pipe, not galvanized. Work must be done by an experienced steamfitter. All state and local codes must be met.

Closed Condensate Return System without Tank: If the condensate is to be returned by gravity in a closed system (no tank and no steam trap), the load discharge should be at least 2 feet above the boiler water level. When applicable, install steam return lines at sufficient height to allow a pitch of 2 inches to 10 feet of pipe length. To make the return connection to the boiler, follow the steps below:

- Remove the boiler blow down valve from the shell and replace through a female ¾" NPT tee with female ports
- Connect the return line with a swing check valve to one of the side ports of the tee, with flow towards the boiler
- Connect the blowdown valve to the other side port of the tee

This system is not recommended where a significant amount of intermittent live steam is being taken from a line over 25 to 30 ft. in length.


Condensate Return System (with Tank): See Instruction Supplement #1.

1.4 Electrical

To hookup power and control voltage to the boiler, please proceed as indicated in FIGURE 1. To ensure proper connection, please refer also to the attached wiring diagram and labels next to the field wiring terminals for proper conductor size and maximum torques that can be applied to the terminal contacts.

WARNING

All wiring must be installed in accordance with the National Electric Code and any local codes that may apply. Wiring must be done by a competent, certified electrician. For this service, the N.E.C. requires supply wires rated at 125% of full load. Use only copper wire. Install a fused disconnect switch within sight of the boiler. Connect power supply to the terminals in control panel.



1.5 Safety Valve

The safety valve is designed to discharge hot steam when the set pressure is exceeded. Ensure that the discharge port is pointing toward the back of the unit away from the operator and any isles. If it is required that discharge piping be installed from the safety valve, the pipe must never be smaller than the valve outlet and must be rigidly supported, placing no weight on the valve itself.

1.6 Blowdown Valve



CAUTION

When the blowdown valve is utilized, a large volume of hot water and steam is discharged. Ensure that this valve is properly piped for this discharge. State and local codes must be met as applicable.

RX36 – RX80 Boiler Models

Element Removal Clearance:
RX36 – 40: ERCL = 0in
RX54 – 80: ERCL = 24in



ERCR = 24in
ERCR = 24in



RXH36 – RXH80 Boiler Models

Element Removal Clearance:
RXH36 – 40: ERCL = 0in
RXH54 – 80: ERCL = 24in



ERCR = 24in
ERCR = 24in



RXHC36 – RXHC80 Boiler Models


Element Removal Clearance:
RXHC36 – 40: ERCL = 0in
RXHC54 – 80: ERCL = 24in

ERCR = 24in
ERCR = 24in




RX100 – RX120 Boiler Models

Element Removal Clearance:
RX100 – 120: ERCL = 36in ERCR = 36in




RXH100 – RXH120 Boiler Models

Element Removal Clearance:
RXH100 – 120: ERCL = 36in ERCR = 36in



RXHC100 – RXHC120 Boiler Models

Element Removal Clearance:
RXHC100 – 120: ERCL = 36in ERCR = 36in



2. Operation

2.1 Basic Operation

STEP 1: Open steam line valve slightly. This will allow the boiler to be filled without producing back pressure.




FIGURE 2

Open the Feed Water Shutoff Valve
Ensure that the Boiler Blowdown Valve is closed.

STEP 2:

Throw the fused disconnect switch (not provided by factory) to the ON-position and turn ON the boiler control voltage.

STEP 3:



FIGURE 3

Turn the POWER switch (1) to the ON-Position.

If the water in the boiler is below nominal level, then the REFILLING light (2) turns ON and water enters the boiler. As soon as the water level reaches approximately 1/2 height of the gauge glass, the automatic refilling device turns off.

NOTICE

Do not let the pump to run dry for an extended time as this will cause damage to the pump.

STEP 4: Close the steam line valve

STEP 5:



If the boiler controller indicates any alarms (3), then press the corresponding RESET button(s) (4).
As soon as no boiler alarms are indicated, the HEATING light (5) turns on and the boiler starts to build up pressure.

Observe the pressure gauge (6) while pressure builds up. The working pressure should have been factory set to your

specification. However, if you wish to change the working pressure setting, proceed as shown in chapter 3.2.

To turn the boiler OFF, proceed as follows:

- Turn the POWER switch (1) of the boiler controller to the OFF-Position
- Turn and lock the fused disconnect switch, installed upstream of the boiler into the OFF-position

2.2 Setting and Changing Boiler Operating Parameters on the Boiler Controller

Under normal conditions, there is no need to change the factory preset boiler operating parameters. However, if conditions such as low water or high water alarm nuisance tripping occurs, if the Automatic Flush & Drain duration needs to be changed and others, then one or more of the boiler operating parameters need adjustment.

2.2.1 Boiler Controller Overview

The boiler controller provides all functions for the operation of the R, RH and RHC boiler models.

Basic Functions:

- Low water cutoff
- Boiler high pressure cutoff
- High water level feed shutoff
- Automatic boiler refill
- Automatic boiler blowoff (Optional)
- Remote controlled boiler ON/OFF and boiler status (Optional)




FIGURE 4

2.2.2 Low Water Cut-Off Function




The low water cutoff module of the boiler controller de-energizes the heating elements when the water level in the boiler pressure vessel falls below the minimum acceptable operating level. It senses the water level in the boiler pressure vessel with the low water cutoff probe E3.


The water level is processed by the low water cutoff module as normal when the tip of the probe E3 is in contact with water. When the water level in the boiler falls below the tip of the probe E3, then it is processed by the control as too low.

This control provides timing against short cycling, which avoids boiler shutdown when the probe E3 loses contact with the boiler water for a short period of time. Once the short cycling timer has elapsed (times are adjustable and can be set as shown below), the control de-energizes the heating elements and turns on the boiler alarm light "LOW WATER". This alarm light indicates that the water level in the boiler shell is too low and that the heating power is locked out. Boiler operation can be resumed only after restoring normal water level in the boiler shell and then pressing the "LOW WATER" reset (R) button. After pressing this button, the alarm light "LOW WATER" turns off and the lockout is removed.

An additional task of the low water cutoff module is to provide manual reset function for the high limit pressure control. If the operating pressure control fails, the steam pressure in the boiler pressure vessel can reach the value set on the high limit pressure control. In that case, the high limit pressure control de-energizes the heating elements. Lockout occurs as described above. The boiler alarm light "HIGH PRESSURE" remains on until the boiler steam pressure falls below the setting of the high limit pressure switch and the "HIGH PRESSURE" reset (R) button is pressed. After pressing this button, the alarm light "HIGH PRESSURE" turns off and the lockout is removed.

The default setting of the low water cutoff module is

Funct	DIP-Switch	Description
1		Low water cutoff function. When the water level in the boiler pressure vessel is too low for more than $t_{\text{lockout}} = 3\text{seconds}$, the low water cutoff module de-energizes and locks out the heating elements.
2		Same as Function1 plus automatic restart after boiler blowdown: Low water cutoff module allows after power on 10minutes boiler refill, while it keeps the heating elements de-energized. During this time no lockout is generated.
3		Same as Function1, but with adjustable time delay t_{lockout} . Time range is 6 to 60seconds.

Funct	DIP-Switch	Description
4		Same as Function2, but with adjustable time delay t_{lockout} . Time range is 6 to 60seconds.

The R, RH and RHC steam boiler models ship with the low water cutoff module configured to Function 2. If low water alarm nuisance tripping occurs in the field usually caused by temporarily overloading the boiler, then change the module configuration to Function 3 by following the instructions below:

WARNING


Do not touch any electrical components of the boiler control circuit before turning OFF all power supplies to the boiler.

- 1 Turn the boiler controller POWER switch OFF. Turn all power supplies to the boiler OFF. Remove the four (4) upper screws from the front panel of the boiler controller and hinge the controller out from the electrical enclosure. On the low water cutoff module (the smaller electronic board) is located the 3-pole DIP-Switch which sets the low water cutoff module functions.
- 2 Move all DIP-switches into the ON-position. Hinge the boiler controller back into the electrical enclosure and attach the controller front panel at the upper left corner with one screw to the electrical enclosure.
- 3 Turn ON the control voltage power supply to the boiler and turn the POWER switch ON
- 4 Set Lockout Time t_{lockout} (applicable only for Function 3 and Function 4)
 - a. Press and hold the "HIGH PRESSURE" reset (R) button
 - b. Press for 1 sec. and release for 1sec. the "LOW WATER" reset (R) button once for each 6seconds of delay time.
- 5 Turn the POWER switch off. Turn all power supplies to the boiler OFF. Remove the screw from the controller front panel upper left corner and hinge the controller out from the electrical enclosure.
- 6 Select Function 4 by sliding the DIP-switches as shown above
- 7 Hinge the boiler controller back into the electrical enclosure and attach the controller front panel with all screws to the electrical enclosure.
- 8 Turn the POWER switch ON for 4seconds
- 9 Turn the POWER switch OFF for 4seconds
- 10 Turn the POWER switch ON for 4 seconds.
- 11 Turn the POWER switch OFF for 4 seconds.
- 12 With the next POWER switch ON, the boiler is ready for operation.

2.2.3 Setting Boiler Operating Functions, Monitors and Parameters

Under normal conditions, there is no need to change the factory preset boiler operating parameters. However, if conditions such as high water level nuisance tripping or if optional additional equipment such as Automatic Flush & Drain, Alarm & Monitoring Interfaces and other equipment is installed in the field, then some boiler operating parameters must be

changed. R, RH and RHC boiler models usually ship with the boiler controller configured set as shown. No adjustments to the boiler controller need to be made in order to operate the boiler.



The left display digit indicates the selected boiler function configuration, whereas the right display digit indicates the boiler monitoring configuration.

Example:

The Boiler Function Configuration “1” selected above indicates that the following boiler functions are enabled:

“Automatic boiler refill function with single probe (E1)” with function parameters:

“Refill ON-delay time” = 0seconds (PAR. NUMBER 20)

“Refill OFF-delay time” = 10seconds (PAR. NUMBER 21)

And

“Pressure Controlled boiler blowdown function” with function parameter:

“Blowdown duration” = 4minutes (PAR. NUMBER 31)

Please refer to **Table1** for all available function configurations and detailed boiler function descriptions.

The Boiler Monitor Configuration “0” selected above indicates that the following boiler monitors are enabled:

“Automatic boiler refill monitor” with parameters:

“Initial automatic boiler refill timeout after power-on = 10minutes (PAR. NUMBER22)

“Automatic boiler refill timeout during boiler operation 1minute (PAR. NUMBER23)

And

“Boiler high water level cut-off monitor”


Please refer to **Table2** for all available boiler monitor configurations and their detailed description.

In order to make changes to the boiler controller configuration, proceed as follows:

a.) Before setting parameters, a pass code must be entered. This keeps unauthorized personnel from changing controller parameters. In order to enter the pass code, follow the steps below:

While the power switch is in ON-position, and the “STATUS”-LED is lit, press and hold the <-> and <E> keys at the same time. With <-> and <E> keys pressed, enter the following sequence on the <+> and <M> keys: <+>, <M>, <+>, <+> and <M>. Once the code is entered correctly, the light on the menu-LEDs toggle from “STATUS” to “PAR. NUMBER” and the controller is ready for boiler operating parameter changes.

Enter <+> <M> <+> <+> <M>




Press and hold these keys

b.) Press the <+> and/or <-> keys to set the boiler operating parameter number. When the parameter number is set, press the <M> key. This will toggle the light on the menu-LEDs from “PAR. NUMBER” to “PAR. VALUE” and the controller is ready for the selected boiler operating parameter value to be set.

Increase parameter number


Press <M>



Decrease parameter number

c.) Press the <+> or <-> key to set the selected boiler operating parameter value.

Increase parameter value



Decrease parameter value

d.) To set the next boiler operating parameter, press the <M> key. Repeat item b.) and c.) until all required boiler operating parameters are set.

e.) To exit the boiler parameter setting menu, press the <E> key. Once the <E> key is pressed, the light toggles from the “PAR. VALUE”-LED to the “STATUS”-LED and the new boiler status is displayed.



The following Tables provide an overview of all available boiler and monitor function configurations (Table1 and Table2). Table 3 provides an overview of all operating parameters used in the boiler and monitor functions.

Table 1: Boiler Function Configurations

PAR. NUMBER	PAR. VALUE	PARAMETER DESCRIPTION
0	0	Boiler-Functions Configuration 0 disabled.
	1	Boiler-Functions Configuration 0 enabled = "0" displayed in left digit of LED-Display. <ul style="list-style-type: none"> - Automatic boiler refill function with single probe (E1), refill ON-delay time = 0seconds, refill OFF-delay time = 3seconds. - Pressure controlled boiler blowdown function (Automatic Flush & Drain) with blowdown duration = 4minutes. (Enable/disable this function with BLOWDOWN ENABLE switch on boiler controller)
1	0	Boiler-Functions Configuration 1 disabled.
	1	Boiler-Functions Configuration 1 enabled = "1" displayed in left digit of LED-Display <ul style="list-style-type: none"> - Automatic boiler refill function with single probe (E1), refill ON-delay time = 0seconds, refill OFF-delay time = 10seconds. - Pressure controlled boiler blowdown function (Automatic Flush & Drain) with blowdown duration = 4minutes. (Enable/disable this function with BLOWDOWN ENABLE switch on boiler controller)
2	0	Boiler-Functions Configuration 2 disabled.
	1	Boiler-Functions Configuration 2 enabled = "2" displayed in left digit of LED-Display <ul style="list-style-type: none"> - Automatic boiler refill function with single probe (E1), refill ON-delay time = PAR. NUMBER20 (0 – 10seconds), refill OFF-delay time = PAR. NUMBER21 (3 – 11seconds). - Pressure controlled boiler blowdown function (Automatic Flush & Drain) with blowdown duration = PAR. NUMBER31. (1 - 20 minutes), (Enable/disable this function with BLOWDOWN ENABLE switch on boiler controller)
3 - 9	0	Boiler-Function Configurations 3 - 9 disabled.
	1	Boiler-Function Configuration 3 - 9 enabled: No functions implemented yet.

Boiler Function Definitions

Automatic boiler refill function with single probe (E1)

Sequence of Events:

- As soon as the POWER switch on the boiler controller is turned off, the boiler controller de-energizes the boiler feed water pump and/or solenoid valve.
- If the POWER switch is turned on:
 - o As long as the water level-probe (E1) is in contact with the boiler water, the boiler controller keeps the boiler feed water pump and/or solenoid valve de-energized.
 - o As soon as the water level-probe (E1) loses contact with the boiler water, the boiler controller energizes the boiler feed water pump and/or solenoid valve after the elapse of the refill ON-delay time (**PAR. NUMBER20**).
 - o As soon as the water level-probe makes contact with the boiler water, the boiler controller de-energizes the boiler feed water pump and/or solenoid valve after the elapse of the refill OFF-delay time (**PAR. NUMBER21**).

Pressure controlled boiler blowdown function

This function requires the Blowdown Valve Actuator and Blowdown Enable Pressure Control installed on the boiler.

Sequence of Events:

- As soon as the POWER switch on the boiler controller is turned on, the boiler controller de-energizes the Blowdown Valve Actuator (B2).
- With POWER switch turned off and as soon as the boiler pressure falls below the setting of the Blowdown Enable Pressure Control (S5), the boiler controller generates a 6second time delay. As soon as this time delay has elapsed, the boiler controller energizes (opens) the Blowdown Valve Actuator (B2) for a time (in minutes) saved in **PAR. NUMBER31**.
- After the time saved in **PAR. NUMBER31** has elapsed, the boiler controller de-energizes (closes) the Blowdown Valve Actuator (B2).

Table 2: Boiler Monitor Configurations

PAR. NUMBER	PAR. VALUE	PARAMETER DESCRIPTION
10	0	Boiler-Monitoring Configuration 0 disabled:
	1	Boiler-Monitoring Configuration 0 enabled = "0" displayed in the right digit of the LED-Display. - Automatic boiler refill monitor. Initial automatic boiler refill timeout after power-on = PAR. NUMBER22 (1 – 30minutes), automatic boiler refill timeout during boiler operation = PAR. NUMBER23 (1- 10minutes) - Boiler High Water Level Cut-Off Monitor.
11	0	Boiler-Monitoring Configuration 1 disabled:
	1	Boiler-Monitoring Configuration 1 enabled = "1" displayed in the right digit of the LED-Display. - Boiler blowdown monitor. Expected automatic boiler refill time after blowdown = PAR. NUMBER32 (0 – 99seconds). - Boiler High Water Level Cut-Off Monitor.
12	0	Boiler-Monitoring Configuration 2 disabled:
	1	Boiler-Monitoring Configuration 2 enabled = "2" displayed in the right digit of the LED-Display. - Automatic boiler refill monitor. Initial automatic boiler refill timeout after power-on = PAR. NUMBER22 (1 – 30minutes), automatic boiler refill timeout during boiler operation = PAR. NUMBER23 (1- 10minutes) - Boiler blowdown monitor. Expected automatic boiler refill time after blowdown = PAR. NUMBER32 (0 – 99seconds). - Boiler High Water Level Cut-Off Monitor.
13 - 19	0	Boiler-Monitoring Configuration 4 - 9 disabled:
	1	Boiler-Monitoring Configuration 4 - 9 enabled: No monitors implemented yet.

Boiler Monitor Definitions

Automatic boiler refill monitor:

Flashing "0" in controller display = this boiler monitor generated an alarm. Press <E> to reset.

Sequence of Events:

- As soon as the POWER switch on the boiler controller is turned off, the automatic boiler refill monitor is disabled.
- After the POWER switch is turned on, the automatic boiler refill-monitor measures the duration of each refilling cycle.
 - o If the feed water pump and/or solenoid valve remains energized for more than the time duration saved (in minutes) in PAR. NUMBER22, the boiler controller de-energizes the feed water pump and/or solenoid valve and displays a flashing "0" on the LED-display. The feed water pump and/or solenoid valve remains de-energized (off) until the "E"-key on the controller's key pad is pressed. As soon as the "E"-key is pressed, the boiler controller displays the current boiler function and monitor configurations again and starts a new refilling attempt. PAR. NUMBER22 should be set to approximately 1.5 x the time that the feed water pump and/or solenoid valve needs under normal operating conditions to fill the completely empty boiler to nominal water level.
 - o As soon as a refilling cycle is completed within the time saved in PAR. NUMBER22, the boiler controller will monitor all following refilling cycles as indicated above, except that it will use the time duration saved (in minutes) in PAR. NUMBER23. PAR. NUMBER23 should be set to approximately 3 x the time that the feed water pump and/or solenoid valve needs under normal operating conditions to refill the boiler from minimum to nominal water level. Usually PAR. NUMBER22 is 4 to 5 times greater than PAR. NUMBER23.

Boiler blowdown monitor

Flashing "1" in controller display = this boiler monitor generated an alarm. Press <E> to reset.

Sequence of Events:

As soon as the POWER switch on the boiler controller is turned on, the boiler blowdown monitor checks whether the boiler blowdown function completed a blowdown cycle while the POWER switch was turned off. If that was the case, then this monitor checks further whether the automatic refilling device (feed water pump and/or solenoid valve) remains on for the minimum expected time saved in PAR. NUMBER32. If the automatic refilling device turns off, before the time saved in PAR. NUMBER32 has elapsed; the boiler controller displays a flashing "1" on the LED-display. All boiler functions remain active. The flashing "1" indicates only that the last boiler blowdown attempt was not successful. As soon as the "E"-key is pressed, the boiler controller displays the current boiler function and monitor configurations again.

Boiler High Water Level Cut-Off Monitor

Flashing "2" in controller display = this boiler monitor generated an alarm. Press <E> to reset, or alarm resets automatically (ref. to Sequence of Events below).

This monitor requires the high water cut-off probe (E2) and steam solenoid valve (SOL2) installed and connected to the boiler. The steam solenoid valve is installed into the steam outlet line of the boiler.

Sequence of Events:

As soon as the high water level cut-off probe (E2) comes in contact with boiler water, the boiler controller turns off the automatic refilling device (feed water pump and/or solenoid valve). At the same time the boiler controller turns off the power to the heating elements, closes the steam outlet line through the solenoid valve (SOL2) and displays a flashing "2" on the LED-display. As soon as probe E2 losses contact with boiler water and PAR. NUMBER40 is set to "0", the boiler controller resumes normal boiler operation automatically. If PAR. NUMBER40 is set to "1", press the "E"-key to resume normal boiler operation.

Table 3:

20	0...10	Automatic boiler refill ON-delay time, in seconds.
21	0...11	Automatic boiler refill OFF-delay time, in seconds.
22	1...30	If PAR. NUMBER 10 = 1: Initial automatic boiler refill timeout after power-on, in minutes.
23	1...10	If PAR. NUMBER 10 = 1: Automatic boiler refill timeout during boiler operation, in minutes.
24		
25		
26		
27		
28		
29		
30	0	Pressure controlled boiler blow-off function (Automatic Flush and Drain) disabled.
	1	Pressure controlled boiler blow-off function (Automatic Flush and Drain) enabled.
31	1...20	Pressure controlled boiler blow-off duration (Automatic Flush and Drain), in minutes.
32	0...99	Expected automatic boiler refill time after blowdown, in seconds.
33		
34		
35		
36		
37		
38		
39		
40	0	Automatic alarm reset after high water cut-off alarm.
	1	Manual reset after high water cut-off alarm.

3. Maintenance

⚠ WARNING

Repair must be performed by experienced personnel. Ensure that the boiler is cold, drained and has no pressure or electricity. All electrical and steam safety precautions must be taken.

3.1 Blowoff

⚠ CAUTION

Stand clear of scalding water and steam. Ensure that the blowdown is safely piped.

All boilers must be blown down periodically to remove minerals, scale and other foreign matter, which accumulate inside the pressure vessel. The concentration of this deposit depends in part upon the condition of the water in the area. When water is naturally soft, or has been softened chemically, boiler blowoffs are required less often than in areas where hard water is found. Water softeners are suggested in hard water areas to minimize the formation of hard scale on heating elements. Another factor affecting water condition is the amount of condensate, if any, that is being returned to the boiler. Since condensate is essentially clean distilled water, it contains very few impurities. If a large part of the condensate is being returned and little make-up water is used, the boiler need not be blown down as often as when little or no condensate is returned to the boiler. We recommend to blowoff newly installed steam boilers once per day until the first heating element and pressure vessel inspection is performed (refer to chapter 3.4). If no significant amount of sediment is found on the bottom of the pressure vessel and on the heating element sheaths, then the boiler blowoff frequency can be reduced accordingly. The safest method to blowoff R-series steam boilers is to install a Reimers Electra Steam properly sized and fully trimmed blowdown tank, model BTANK-16 (Figures 5 and 6). Reimers blowdown tanks are designed and constructed to Section VIII of the A.S.M.E. Code and inspected by a commissioned National Board Boiler inspector.

Blowdown Tank Installation

Pipe the blowdown tank to the steam boiler, cold water line and drain as shown in the Figures below. All piping must conform to the A.S.M.E. B31.1 Power Piping Code. The blowoff line between steam boiler and blowdown tank shall be made of black SCH80 steel pipe and the pipe fittings shall be of black steel. **No galvanized piping for this service!** The vent pipe must be 3" NPT, not longer than 50ft. and should be vented without any restrictions to the atmosphere with a minimum of turns. Pipe the blowdown tank to a safe place of discharge.

Boiler blowoff can be performed either manually (Figure 5) or fully automatic (Figure 6). Reimers Electra Steam offers two fully automatic boiler blowoff options:

- a.) Cost efficient boiler pressure triggered blowoff (Automatic Flush & Drain) package, model OPT1016 for applications in which the boiler operates during daytime and is shutdown during nighttime.
- b.) Timer triggered blowoff package, model OPT1001 when boiler operates 24/7

If one of the fully automatic blowoff options is installed and the blowdown tank drains directly to the sewer, we recommend the installation of the automatic after cooler package, model OPT1027 into the blowdown tank drain line.




Figure 5



Figure 6

- Ensure that blowdown tank gauge glass (1) is half filled with water. If not, open the cold water injection valve (2) and fill blowdown tank until water level reaches half height of gauge glass.
- Ensure that the Tri-o-meter (3) indicates a temperature of not more than 70° F. If not, open the cold water injection valve until the temperature of 70° F is reached.
- Ensure that the boiler gauge glass (4) is filled approximately 1/3 with water
- Ensure that the boiler pressure gauge (5) indicates at least 15psi
- Turn boiler power switch (6) to OFF-position
- Close the boiler steam valve (7) and blowoff line drain valve (9)
- Open the boiler blowoff valve (8) and leave open until the water level drops out of the boiler gauge glass (4)
- Close the boiler blowoff valve (8)
- Open the boiler steam valve (7)
- Turn boiler power switch (6) to ON-position and resume boiler operation.

Boiler Pressure Triggered Blowoff (Automatic Flush & Drain)

- Turn boiler power switch (6) in the evening to OFF-position
- Close boiler steam valve (7)
- Ensure that the blowoff line drain valve is closed
- As soon as boiler pressure drops during night time below the setting of the Automatic Flush & Drain pressure switch S4, the motorized blowoff valve (10) opens for a preset time in the boiler controller (see chapter 2.2.3)
- In the morning, turn the boiler power switch (6) to the ON-position. Boiler resumes automatically normal operation

Timer Triggered Boiler Blowoff

- Boiler blowoff occurs in accordance with the blowoff timer setting. After completion of the blowoff, boiler resumes normal operation.

3.2 Pressure Adjustment



Before opening the electrical enclosure, ensure that all power supplies to the boiler are disconnected.




Figure 7

Disconnect all boiler power supplies.
Open the electrical enclosure door.
This gives access to the boiler pressure controls.


S1: Pressure High Limit Control

DO NOT change the setting of this control!

S4: Automatic Flush & Drain Pressure Control (see chapter 3.1)

S2: Operating Control High Setting: Turn the black knob of this pressure control clockwise to increase and counterclockwise to decrease the boiler working pressure (See Figure 7a).

S3: Operating Control Low Setting: All boilers models equipped with 3 or 4 heating elements, or models with a nominal Amp draw of more than 120Amps are equipped with a second operating pressure control. This control should be set approximately 5psi below the setting of S2 in high pressure boilers (safety valve setting above 15psi) and approximately 2psi in low pressure boilers (safety valve setting of 15psi and lower) for power staging.



To change the pressure control setting, turn the black knob until its upper edge is aligned with the desired pressure shown on the scale.

Figure 7a

3.3 Safety Valve Test

Perform this test minimum once per month. Safety valve should be tested at nominal operating pressure.



Stand clear of safety valve and scalding steam.

Hold trip lever open for five seconds in order to flush off valve seat. Permit valve to "slap" shut. If a leak occurs, repeat this test or replace the valve.

3.4 Inspecting the Heating Elements and Pressure Vessel



Ensure that the boiler is cold, drained and has no pressure or electricity

Inspect heating elements and inner walls of pressure vessel every six months. If element rods are covered with scale or other foreign matter, check feed water quality. Clean element rods with stiff wire brush.



Figure 8

- Remove the round ends from the cylindrical shell wrapper
- Disconnect and label terminal wires
- Remove all 4 nuts from the flange of each element that has to be replaced and pull out heating element
- Clean flange surface before installing new element and gasket

If the bottom of the pressure vessel is covered with a significant amount of sludge then remove same from pressure vessel, increase blowdown frequency and check boiler feed water quality (see chapter 1.2)

It is normal that the inner walls of the pressure vessel be covered by a layer of red or brown or black layer of rust. However, rough pressure vessel surface and layers of rust peeling off the surface are an indication for severe corrosion. In such case, contact a water treatment company to check your boiler feed water chemistry (see also chapter 1.2).

3.5 Cleaning the Water Level Probes and Water Level Probe Baffle

⚠ WARNING Ensure that the boiler is cold, drained and has no pressure or electricity

The water level probe baffle is located inside the pressure vessel. It protects the water level probes from being contaminated by foam and other foreign matter that may float on the surface of the boiler water. The water level probe baffle should be inspected after 3 months of operation and then once per year or more frequently, depending on the water quality (refer to chapter 1.2 of this manual to determine proper water quality):




Figure 9

- a.) Remove the water level probe cover and remove each probe. Caution: The water level probes have different lengths. Remove one probe at a time to avoid the installation of the probes in the wrong place. The probe E3 is the longest, whereas probe E2 is the shortest. Please refer to Figure 13 to identify proper probe location. Inspect the probe rods and the PTFE insulations for rust and calcium deposits and clean if necessary. Leave probe E3 removed from shell until the below cleaning procedure is completed.
- b.) Remove the shell end cap
- c.) Remove this pipe plug from the boiler blowoff line




Figure 9a

- a.) Insert an approximately 2ft. long 1/4" OD copper tubing through the shell opening of the probe E3 until it reaches the bottom of the pressure vessel.
- b.) Pull the copper tubing out of the pressure vessel and insert it again through the boiler blowoff line
- c.) Repeat items a.) and b.) several times to ensure that the bottom portion of the probe baffle is cleared of sediments.
- d.) Install all components, bring boiler up to pressure and perform a boiler blowoff

3.6 Gauge Glass Replacement

Replace gauge glass minimum once per year.




WARNING Ensure that the boiler is cold, drained and has no pressure or electricity



Close gauge glass valves (top and bottom).

Figure 10a



Remove gauge glass protector rods

Figure 10b




Open drain valve on bottom fixture to drain glass

Figure 10c



Loosen nuts at top and bottom of glass

Figure 10d



Slide glass up, pull out on bottom of glass and remove.

Figure 10e

f.) Install glass by reversing above procedure. Always install new rubber washers.

4. Trouble Shooting

Boiler Status	Quick Fix
POWER switch on boiler controller turned on, but no lights lit on the front panel of the boiler controller	<ul style="list-style-type: none"> - Check circuit breaker or fuse of the wall outlet where the boiler control voltage circuit is hooked up to. If the circuit breaker is tripped or the fuse blown, check whether other appliances are plugged into outlets that are fed by the same circuit breaker/fuse. If that is the case, then plug those other appliances into outlets that are protected by other circuit breakers or fuses.
LOW WATER alarm light on boiler controller panel lit:	<ul style="list-style-type: none"> - Press the LOW WATER reset switch - Check Water Level. Water level must be visible in gauge glass. - Check the probe wires for continuity - Check if feed water is available - Check feed water pump and/or solenoid valve for proper operation
HIGH PRESSURE alarm light on boiler controller panel lit:	<ul style="list-style-type: none"> - Press the HIGH PRESSURE reset switch - If the pressure gauge indicates steam pressure above the preset value, reduce pressure and press the HIGH PRESSURE reset switch again. - Check operating pressure switch for proper operation
Unit won't build up pressure when POWER switch is on, boiler filled to nominal water level with water and HEATING light on the boiler controller is lit.	<ul style="list-style-type: none"> - Voltage Test: Read voltage across each element. If no voltage reading, check the voltage before and after the element contactor. If no voltage before the contactor, check fuses in fused disconnect switch. If no voltage reading after the contactor and contactor pulled in, replace contactor. If voltage reading after the contactor, go to Amperage Test. - Amperage Test: Read amperage on each element wire. If no amperage reading on one or more element wires, replace heating elements.
Pump and/or solenoid valve energized, but no water enters the boiler	<ul style="list-style-type: none"> - Check water inlet strainer - Check whether the water feed shutoff valve is open
Boiler overfills or floods	<ul style="list-style-type: none"> - Check water feed solenoid valve for sticking - Check the float control wires to the boiler controller for continuity - Check feed water. Boiler won't operate with distilled or de-mineralized water
Fuse blown	<ul style="list-style-type: none"> - Short circuit or overload has occurred. Before replacing fuse, locate the short circuit or overload. - Poor contact between fuse and fuse clips can also cause fuse to blow. If surface that makes contact with the fuse clips is discolored, fuse has been making poor contact with the clips. Installing a larger fuse will not help. Replace the fuse holder.
Contactor(s) don't pull in	<ul style="list-style-type: none"> - Ensure that the contactor coil is receiving proper voltage - If contactor pulls in but chatters, clean magnetic core of contactor - Further problems would indicate mechanical difficulties within the contactor. - Complete contactor replacement is usually the least expensive solution
"REFILLING" light on the boiler controller is lit, but feed water pump or solenoid valve not energized	<ul style="list-style-type: none"> - Check for pump and solenoid valve wiring circuits

If trouble shooting did not resolve problem, please contact our service technicians at:

Phone: 540-662-3811

Email: sales@reimersinc.com

LIVECHAT www.reimersinc.com

5. Parts List for Models RX36 - 120 Electric Steam Boilers

Pos.	Part Number	Part Description
1	02616	BLOCK POWER DISTRIBUTION 3-2/0
	02618	BLOCK POWER DISTRIBUTION 3-500
2	02530	CONTACTOR 50A 120V 3P UL/CSA
	02539	CONTACTOR 75A 120V 3P UL/CSA
	02597	CONTACTOR 93A 120V 3P UL/CSA
3	02601	ELEMENT 208V, 15KW
	02186	ELEMENT 240V, 15KW
	02187	ELEMENT 480V, 15KW
	02411	ELEMENT 600V, 15KW
	02190	ELEMENT 208V, 18KW
	02189	ELEMENT 240V, 18KW
	02611	ELEMENT 380V, 18KW
	02188	ELEMENT 480V, 18KW
	02550	ELEMENT 600V, 18KW
	02600	ELEMENT 208V, 20KW
	03342	ELEMENT 380V, 20KW
	02602	ELEMENT 480V, 20KW
	02603	ELEMENT 600V, 20KW
	02604	ELEMENT 240V, 25KW
	02605	ELEMENT 480V, 25KW
	02606	ELEMENT 600V, 25KW
	02674	ELEMENT 208V, 30KW
	02608	ELEMENT 240V, 30KW
	03267	ELEMENT 380V, 30KW
	02609	ELEMENT 480V, 30KW
	02610	ELEMENT 600V, 30KW
4	02022	FLANGE GASKET 2" RING
5.1	02125	FUSE 250V 15A
5.2	02655	FUSE 250V 5A
6	02128	FUSE 250V 40A
	02127	FUSE 250V 50A
	02127	FUSE 250V 60A
	02129	FUSE 250V 80A
	02130	FUSE 250V 100A
	02453	FUSE 600V 20A
	02134	FUSE 600V 30A
	02135	FUSE 600V 40A
	02518	FUSE 600V 50A
	03349	FUSE 600V 80A CLASS J
7	02140	FUSE BLOCK 250V 30A 1P
8	02142	FUSE BLOCK 250V 60A 3P
	02144	FUSE BLOCK 250V 100A 3P
	02150	FUSE BLOCK 250V 30A 2P
	02613	FUSE BLOCK 600V 30A 3P
	02614	FUSE BLOCK 600V 60A 3P
	03770	FUSE BLOCK 600V 100A 3P
9	02420	GAUGE GLASS 6.0" X 0.625" PYREX
10	02006	GAUGE RUBBER WASHER FOR .625" GLASS
	02448	WASHER BRASS
11	02396	WATER GAUGE FIXTURE SET

12.2	MBJ057	ELECTRODE FITTING
12.1	MBJ175	
12.3	MBJ187	
13	04162	PRESSURE CONTROL 14# OPERATING
	04163	PRESSURE CONTROL 60# OPERATING
14	04296	PRESSURE CONTROL 90# HI LIMIT
15	02329	PRESSURE GAUGE 2.5" 160#
	02451	PRESSURE GAUGE 2.5" 30#
16	03399	PUMP 1/3HP 120V 1PH CR
	03401	PUMP 1/3HP 240V 1PH CR
	02360	PUMP 1/3HP 120 – 240V CT
	04272	PUMP 1/2HP 120 – 240V CT
	05008	PUMP 1/3HP 120V 1PH
17	20838	BOILER CONTROLLER
18	02456	STRAINER .5" "Y"
19	04463	VALVE 3-WAY .25" FEMALE NPT
20	02490	BALL VALVE ½"
	02514	BALL VALVE ¾"
21	03802	BALL VALVE WITH LATCH ¾"
22	02692	CHECK VALVE ½" BALL CONE ½"
23	02462	CHECK VALVE ½" SWING
24	02012	GLOBE VALVE ¾" SWP 125#
	02163	GLOBE VALVE 1" SWP 125#
	02712	GLOBE VALVE 1-1/4" SWP 125#
25	02636	SAFETY VALVE ½" 50#
	02638	SAFETY VALVE ½" 75#
	02637	SAFETY VALVE ½" 100#
	02010	SAFETY VALVE ¾" 15#
	02641	SAFETY VALVE ¾" 75#
26	02301	SOLENOID VALVE ½" 120V
	02579	SOLENOID VALVE COIL FOR #02301
	02300	SOLENOID VALVE ½" 240V




Figure 11




Figure 12




Figure 13




FIGURE 14

INSTRUCTION SUPPLEMENT NO. 1

CONDENSATE RETURN SYSTEM

The following Condensate Tanks are furnished as standard equipment on Model RHC Boilers, with Serial No. 17000 and up:

Tank size for Models 24 thru 120 ----- 16 gallons

INSTALLATION

1. Connect water supply to water intake on tank.

NOTE:

Water supply should be turned off when boiler is not in operation.

2. Connect condensate return line from equipment to condensate return intake.
3. Pipe from vent is to be installed to outside of building, if desired. If this method is used, pipe should be the same size as vent opening. Under no condition should vent be plugged.
4. Install piping from overflow to drain.
5. Pressure reducing valve required for city water pressures in excess of 40 PSI.

MAINTENANCE

1. **STRAINER** - should be removed and cleaned shortly after boiler has been in operation to clear away sediment which may have accumulated during start-up. This strainer should be periodically inspected and cleaned when necessary.
2. **GAUGE GLASS** - See boiler instructions.
4. **PUMP MOTOR** - Maintenance is not normally required on the pump or motor.

CONDENSATE RETURN SYSTEM PARTS LIST

PART#	DESCRIPTION
02005	GAUGE GLASS 5/8" X 7"
02001	GAUGE GLASS FIXTURE SET
02027	STRAINER 1"
02358	SCREEN FOR STRAINER
02360	PUMP/MOTOR 120/240 1PH 1/3 HP CT

MAKE-UP VALVE ASSEMBLY

- (1) 02070 VALVE ASSEMBLY
- (2) 02085 FLOAT BALL
- (3) 02086 GASKET
- (4) 02024 COMPLETE ASSEMBLY

